

# Installation Instructions

## Platiere Vanity Sconce

### Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

### To Assemble

1. Install the beveled mounting disc to the J-box using the supplied machine screw hardware (2X).
2. Hold the wall plate next to the J-Box, and connect the wires to those in the J-box using the Wago wire connectors.
3. Loosen the set screws (2X) at the 12:00 and 6:00 position on the sconce wall plate and press the sconce over the mounting disc, flush with the wall.
4. Level the sconce and tighten the set screws (2X) to finalize the installation.
5. Screw in all the bulb (2X).  
\*DO NOT OVER TIGHTEN THE BULBS\*
6. Attach the back shades (2X) to the sconce body using the provided thumb screws and O-rings. Then, repeat the process to secure the front shades (2X).
7. Turn on the power and check that good connections have been made.

### Care Instructions

- Wipe with a soft cloth. Do not use chemical cleaner.

