

# Installation Instructions

Montfaucon Sconce

## Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

## To Assemble

1. Hold the socket assembly up inside of the porcelain cone so that the screw holes are aligned.
2. Screw in the bumper assembly by holding it against the cone with the holes aligned. DO NOT OVERTIGHTEN
3. Push the wall plate up against the stem of the bumper assembly and fasten the washer and nut.
4. Install the beveled mounting disk to the J-box using the supplied mounting screw hardware (2X).
5. Using the supplied wire nuts, connect the wires to those from the J-box
6. Remove the set screw at the 12:00 position on the sconce back plate and press the sconce over the mounting disk, flush with the wall.
7. Level the sconce and tighten the set screw to finalize the installation.
8. Screw in the bulb and turn on the power to confirm you have made good wire connections.

## Care Instructions

- Wipe with a soft cloth. Do not use chemical cleaner.

