Installation Instructions

Chartier Hanging Sconce

Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

To Assemble

- 1. Install the beveled mounting disc to the J-box using the supplied mounting screw hardware (2X).
- 2. Hold the wall plate next to the J-Box, and connect the wires to those in the J-box using the Wago wire connectors.
- 3. Loosen the set screws (2X) at the 12:00 and 6:00 position on the sconce wall plate and press the sconce over the mounting disc, flush with the wall.
- 4. Level the sconce and tighten the set screws (2X) to finalize the installation.
- 5. Gently squeeze the shade bracket to allow the bracket to pass through the interior of the shade until the foot of the bracket is below the crystal.
- *DO NOT LET GO OF THE SHADE UNTIL THE BULB IS INSTALLED*
- 6. Slide the shade up along the cord and screw in the bulb. *DO NOT OVER TIGHTEN THE BULBS*
- 7. Slide the shade down into place. Ensure the bracket ledge sits beneath the shade to securely hold it in place.
- 8. Turn on the power and check that good connections have been made.
- *Do not leave the crystal hanging without the bulb installed at any given time. When changing the bulb, make sure to hold the crystal, so it can not fall.*

Care Instructions

• Wipe with a soft cloth. Do not use chemical cleaner.

