

Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

To Assemble

1. Install the beveled mounting plate to the J-box using the supplied machine screw hardware (2X). Use appropriate anchors and screws as needed. Additional mounting holes are provided.
2. Hold the wall plate next to the J-box, and connect the wires to those in the J-box using the Wago wire connectors.
3. Loosen the set screws at the 12:00 and 6:00 position on the sconce wall plate and press the wall plate over the mounting disc, flush with the wall.
4. Level the wall plate and tighten the set screw (2x).
5. Screw in the bulb. *Do not overtighten.*
6. Slide the shade onto the wall plate slot and secure it using thumb screws (2x).
7. Turn on the power to confirm you have made good wire connections.

Care Instructions

- Wipe with a soft cloth. Do not use chemical cleaner.

