## **Installation Instructions**

**Apollinaire Sconce** 

## **Important Safety Instructions**

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

## To Assemble

- 1. Install the beveled mounting disc to the J-box using the supplied mounting screw hardware (2X).
- 2. Hold the sconce body next to the J-Box, and connect the wires to those in the J-box using the wire nuts.
- 3. Remove the set screw at the 12:00 position on the sconce body and press the sconce over the mounting disc, flush with the wall.
- 4. Level the sconce and tighten the set screw.
- 5. Push the Lead Crystal up with your hand to more easily screw in the bulbs (1X).
- 6. Turn on the power to confirm you have made good wire conections.

## **Care Instructions**

• Wipe with a soft cloth. Do not use chemical cleaner.

