

Installation Instructions

Montfaucon 3 Light Pendant

1. Please ensure the power is off before making any electrical adjustments.

2. Place the wire cover on the pendant body and over the wire nuts.

3. Separate the cap, drop rod and all-thread. Feed the wires through the cap and the all-thread. Screw the all-thread into the pendant body.

4. Place the drop rod through the riser and over the all-thread. Allow enough all-thread exposed through the ceiling plate to fasten the nut and washer. Tighten the riser against the ceiling plate with the set screws

5. Separate the Pendant Body, Outside Bumper, and Socket Assembly. Place the socket assembly inside the porcelain cone and feed the quick connects through the largest hole opening. Screw the Outside Bumper to the Socket Assembly using the two machine screws. ****DO NOT OVERTIGHTEN.**

6. Connect the quick connects of the socket assembly to those sticking out of the body. Now tighten the next two machine screws into the Outside Bumper.

7. Repeat Step 6 for the for the two other shades.

8. Install the beveled mounting disc to the J-Box using the supplied hardware.

9. Position the entire pendant over the beveled mounting disc and connect the leads to those in the J-Box with the wire nuts. Make sure the ceiling plate is flush with the ceiling.

10. Using the provided allen wrench, tighten the three set screws through the ceiling plate and onto the mounting disc tightly.

11. Screw in each bulb and turn on the power to ensure good wire connections. Do not overtighten the bulbs.

