

Installation Instructions

Montalembert Linear Chandelier

1. Make sure the power to the J-Box is turned off.

2. Feed the electrical wires through one of the Drop Rods while inserting the threaded connectors (2X) and drop rods (2X) into the Main Body.

3. Insert the threaded connectors (2X) into the Drop Rods and through the Ceiling Plate.

4. Fasten each nut and washer (2X) over the threaded connectors to secure the fixture to the ceiling plate.

5. Attach the Mounting Plate to the ceiling. Additional holes are added to the Mounting Plate to allow for extra mounting hardware (not provided), depending on various ceiling constructions. Anchors or ceiling blocking is strongly advised.

6. Hold the chandelier near the ceiling and connect the wires from the chandelier to those in the Junction Box using the supplied wire nuts.

7. Push the Ceiling Plate over the Mounting Plate flush with the ceiling and tighten all 6 set screws.

8. Screw all 12 bulbs into the sockets. ***DO NOT OVERTIGHTEN THE BULBS*** It will result in damage to the socket.

9. Place all 12 glass shades over the bulbs, resting on the shade holder.

10. Turn on the power and check that good connections have been made.

