

Installation Instructions

Anthéron Flushmount

Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

To Assemble

1. On a flat surface, place the cast glass and slide the 3x bracket in the slots on the cast glass. Place the main body on top of the bracket and cast glass and align the screw holes on the main body to those in the brackets. Secure the cast glass to the main body by screwing 6x screw as shown.
2. Use the supplied machine screws (2x) to fasten the mounting disc to the J-Box.
3. Additional holes are added to the mounting disc to allow for extra mounting screw hardware (not provided), depending on various ceiling constructions. Anchors or ceiling blocking is strongly advised.
4. Bring the ceiling plate sub assembly closer to the mounting plate. Using the supplied wire nuts, connect the wires from the ceiling plate sub assembly to those in the J-box.
5. Place the ceiling plate sub-assembly flushed with the mounting plate, align the thumb screw holes, and secure it using 3x thumb screw.
6. Screw in each light bulb (3x). Do not over-tighten.
7. Push the main body over the mounting disc, flush with the ceiling and tighten the 3x set screw using the supplied allen key.
8. Turn on the power to ensure you have made good wire connections..

