

Important Safety Instructions

- Turn off all power to the Junction Box before making any electrical adjustments.
- Always disconnect the power before installing/replacing bulbs, during cleaning or maintenance.
- To avoid the risk of fire, do not exceed the recommended wattage.
- Consult a qualified, licensed electrician before installation.

To Assemble

1. Install the beveled mounting disc to the J-box using the supplied machine screw hardware (2X).

2. Additional holes are added to the mounting disc to allow for extra mounting screw hardware (not provided), depending on various ceiling constructions. Anchors or ceiling blocking is strongly advised.

3. Hold the ceiling plate near the installed mounting disc, and using the supplied lever nuts, connect the wires from the fixture to those in the J-box.


4. Loosen each set screw (4X) at the 90° position on the ceiling plate.

5. Push the ceiling plate over the mounting disc, flush with the ceiling, and tighten each set screw (4X).

6. Slide the glass shade over the socket cover and secure it by screwing in the threaded ring to the socket cover.

7. Screw in the bulb. *Do not over-tighten the bulb.*

8. Turn on the power to confirm you have made good wire connections.

**Care Instructions**

- Wipe with a soft cloth. Do not use chemical cleaner.